

The notification may not be dispensed with by conventions; however, the time [of flight] may be amended or the notifications may be made once for several flights.

Section 11. Foreign aircraft which do not cross the border at the fixed time and place lose the right granted by the permission, and, in order to fly over, must request permission anew.

If such aircraft is damaged in the course of the trip or [has] excusable reasons and is able to fly over within 48 hours after the expiration of its time, it may ask by radiocable for an eventual prolongation of the time for flying over.

Section 12. As military aircraft shall be considered all [those] which:

- (1) have military persons among the crew (whether or not in uniform);
- (2) are included in the [military] air forces of a State;
- (3) carry arms or are equipped for carrying such [arms]; or
- (4) carry still cameras, movie cameras, or military equipment for observation or measurement [mapping].

Section 13. Foreign aircraft, when flying over Bulgarian territory, may not carry prohibited objects and persons. In case of violation, the object shall be confiscated, and the persons [shall be] detained.

Foreign aircraft may not carry: arms, explosives, military equipment, still cameras, movie cameras, pigeons and radio sets, with the exception of the radio sets which are aboard. They [the foreign aircraft] may be allowed to carry light weapons.

CHAPTER THREE—FLIGHT, LANDING AND DEPARTURE OF AIRCRAFT

Section 14. Aircraft may land on, and take off, from an airport, and in case of distress must try to land only on empty, unfenced places or on water.

No objects shall be thrown out of the aircraft except in cases of emergency.

Use of combat material on board aircraft shall be prohibited.

Section 15. Aircraft may not fly over inhabited areas, railroad stations, factories, construction [sites], electrical centers, dams, bridges, antennas, aircables, and the like at a height below 500 meters, nor perform acrobatic flights over such places, and over inhabited areas at a height below 800 meters.

Section 16. A foreign aircraft which has permission to fly over the country [Bulgaria] must cross the border at the place and time assigned and fly no higher than 500 meters measured from the highest point within a region of 5 kilometers; [must] fly in corridors as specified in the permission, without delay and deviation from its route; and [must] land only at the airport of Vrazhdebna [near Sofia] or at the airport specified in the [international] convention or the permission.

Section 17. After landing at the airport, the commanding officer of the foreign aircraft must present his documents and file a questionnaire-declaration, submitted to him by the airport authorities. Thereafter, the commanding officer, the crew and the passengers shall facilitate the control upon them and the aircraft. They shall observe the order of the airport and all police, customs, sanitary and financial