

SECTIONS II thru IV
Paragraphs 2-25 thru 2-28

2-25 STORAGE.

2-26 Inside storage with Shockpan assembly installed is recommended for the LAU-3/A Rocket Launcher. Fairings should be stored in their sealed shipping cartons until ready for use.

2-27 DISPOSAL.

2-28 Any launcher or component found to be unserviceable is to be reported for disposition in accordance with Paragraph 19, Section 28, Volume I of AFM 67-1.




Figure 2-9. Rocket Release Tool

SECTION III
OPERATING CHECKS AND ADJUSTMENTS
 NOT APPLICABLE

SECTION IV
EMERGENCY OPERATION AND REPAIR
 NOT APPLICABLE